

# Hydret 2

## Pre- and post-spotting agent for use in water

**Hydret 2** solubilizes blood, albumen, food, dairy products, ice cream, cream, beer, chocolate, cacao, sweat, pigment soil, urine and similar albuminous stains.

### Application:

Apply **Hydret 2** on the stain and treat with a soft brush. In case of aged stains or stains difficult to remove, allow to react for a longer time. Frequently remoisten the stained area to intensify the solubilizing power.

When used in pre spotting, rinse in the machine and, on the post-spotting table, rinse with water.

In case of strongly aged albuminous stains, we recommend to use in addition **Lipazol L**.

### ATTENTION:

- Do not treat albuminous stains with steam or spotting agents containing acid as this will lead to stain fixing.
- In case of sensitive textiles, dyes and prints, we recommend to try the product reaction on the seam prior to spotting.
- Do not intermix spotting agents !

### HEALTH AND SAFETY RECOMMENDATIONS:

**Precautions:** Keep out of the reach of children. When using do not eat or drink. Avoid contact with skin and eyes. Wear suitable gloves and eye/face protection.

**First Aid:** In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. After contact with skin, take off immediately all contaminated clothing and wash immediately with plenty of water. In case of accident or if you feel unwell, seek medical advice immediately (show the label where possible). If swallowed, seek medical immediately and show this container or label

**ONLY TO BE USED BY PROFESSIONAL TEXTILE CLEANERS !  
FOR INDUSTRIAL USE ONLY !**

The information provided herein is given on an advisory basis which does not imply any liability on our part. For further details **see our relevant safety data sheet prior to use !**