

V 2

Pre- and post-spotting agent for use in perchloroethylene

V 2 solubilizes blood, albumen, food, dairy products, ice cream, cream, beer, chocolate, cacao, sweat, pigment soil, urine and similar albuminous stains.

Application:

Apply V 2 on the stain and treat with a soft brush. In case of aged stains or stains difficult to remove, let react longer time. Frequently remoisten the stained area to intensify the solubilizing power.

When used in pre-spotting, rinse in the machine and, on the post-spotting table, rinse with water.

In case of strongly aged albuminous stains, we recommend to use in addition **Lipasol L**.

ATTENTION:

- Do not treat albuminous stains with steam or spotting agents containing acid as this will lead to stain fixing.
- In case of sensitive textiles, dyes and prints, we recommend to try the product reaction on the seam prior to spotting.
- Do not intermix spotting agents.

HEALTH AND SAFETY RECOMMENDATIONS:

Precautions Keep out of the reach of children. When using, do not eat or drink. Avoid contact with skin and eyes.

First Aid: In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. After contact with skin, take off immediately all contaminated clothing and wash immediately with plenty of water. In case of accident or if you feel ill, seek medical advice immediately (show the label when possible). If swallowed, seek medical advice immediately and show this container or label.

**ONLY TO BE USED BY PROFESSIONAL DRYCLEANERS !
FOR INDUSTRIAL USE ONLY!**

The information provided herein is given on an advisory basis which does not imply any liability on our part. For further details **see our relevant safety data sheet prior to use !**